General Owner's Information

Vehicle Id	entificat	ion Nu	mber (\	/IN):	П		
Owner No	ıme:						
Address:							

Your satisfaction is our #1 goal. If you have questions or concerns about your vehicle, we suggest you follow these

Phone:

- Contact your Sales Representative or Service Advisor at your selling/servicing dealership.
- 2. If the inquiry or concern remains unresolved, contact the Sales Manager or Service Manager at the dealership.
- If the inquiry or concern cannot be resolved at the dealership level, please contact the Ford Customer Assistance Center.

In the US, contact:

Ford Motor Company Customer Assistance Center 16800 Executive Plaza Drive P.O. Box 6248 Dearborn, Michigan 48126 1-800-392-3673 (FORD) TDD for the hearing impaired: 1-800-232-5952

In Canada, contact:

Customer Assistance Center Ford Motor Company of Canada, Limited

P.O. Box 2000 Oakville, Ontario L6J 5E4 1-800-565-3673 (FORD)

Outside the US or Canada, contact:

Ford Motor Company Worldwide Direct Market Operations

1555 Fairlane Drive Allen Park, Michigan 48101 U.S.A. Telephone: (313) 594-4857 Fax: (313) 390-0804 **General Owner's Information**

Find Your Way

Table of Contents

General Owner's Information
Find Your Way
General Maintenance Information
Owner Checks and Services
Normal Schedule
Mileage Intervals 1
Exceptions 3
Special Operating Conditions 3
Maintenance and Service Record 3

All rights reserved. Reproduction by any means, electronic or mechanical including photocopying, recording or by any information storage and retrieval system or translation in whole or part is not permitted without written authorization from Ford Motor Company.

Copyright © 1999 Ford Motor Company

Find Your Way

Symbol Key



Cars and Minivans



Light Trucks, Sport Utilities, and Vans



4x4 Vehicles



Diesel



Natural Gas Vehicles (NGV) and Propane



Towing a trailer or using a camper or car-top carrier



Extensive idling and/or low-speed driving for long distances as in heavy commercial use such as delivery, taxi, patrol car or livery



Operating in dusty conditions such as unpaved or dusty roads



Off-road operation

General Maintenance Information

Why Maintain Your Vehicle?

This guide describes the scheduled maintenance required for your vehicle.

Carefully following this schedule helps protect against major repair expenses resulting from neglect or inadequate maintenance and may also help to increase the value of your vehicle when you sell or trade it.

It is your responsibility to see that all scheduled maintenance is performed and that the materials used meet Ford engineering specifications. Failure to perform scheduled maintenance specific in this guide will invalidate warranty coverage on parts affected by the lack of maintenance. Be sure receipts for completed maintenance are kept with the vehicle and confirmation of the work performed is always recorded in this guide.

Your Ford or Lincoln Mercury dealer, or Ford or Lincoln Mercury Auto Care service center has factory trained technicians who can perform the required maintenance using genuine Ford parts. They are committed to meeting your service needs and to assuring your continuing satisfaction.

Protecting Your Investment

Maintenance is an investment that will pay dividends in the form of improved reliability, durability and resale value. To assure the proper performance of your vehicle and its emission control systems, it is imperative that scheduled maintenance be completed at the designated intervals.

Ford strongly recommends the use of genuine Ford replacement parts. Parts other than Ford, Motorcraft or Ford authorized remanufactured parts that are used for maintenance replacement or for the service of components affecting emission control must be equivalent to genuine Ford Motor Company parts in performance and durability. It is the owner's responsibility to determine the equivalency of such parts. Please consult your Warranty Guide for complete warranty information.

General Maintenance Information

PCV Valve Replacement

The PCV valve is a critical emission component. For the 2000 model year Ranger light truck equipped with 2.5L 4 cylinder engine, the dealer will replace the PCV valve free of charge at **60,000 miles** except in Canada, on California certified vehicles registered in California, and on California certified vehicles registered in states that have adopted California standards. The valve should be replaced again at **120,000 miles**, but this will be at the owner's expense.

For all passenger cars and light trucks under 6,000 Gross Vehicle Weight (GVW), regardless of engine the PCV valve should be replaced at 100,000 miles. This replacement will be at the owner's expense.

For all light trucks over 6,000 GVW, regardless of engine, the PCV valve should be replaced at **120,000 miles**. This replacement will be at the owner's expense.

If you are unsure about your engine type or GVW ask your dealer.

Which Maintenance Schedule Should You Follow?

Normal Schedule

The Normal Schedule applies to those who operate their vehicle under typical, everyday driving conditions. The maintenance frequency represented in this schedule typifies what the vast majority of vehicle operators will require. The listed services should be performed at specified mileage intervals.

General Maintenance Information

Special Operating Conditions

If you operate your Ford/Lincoln/Mercury primarily in one of the more demanding "Special Operating Conditions" listed below, you will need to have some items maintained more frequently, see page 35. If you only occasionally operate your vehicle under these conditions, it is not necessary to perform the additional maintenance. For specific recommendations, see your dealership service advisor or qualified service professional.

These special operating conditions are:

- Towing or carrying heavy loads
- Extensive idling and/or driving at low-speeds for long distances
- Driving in dusty conditions
- Off-road operation

Exceptions

In addition, there are several exceptions to the Normal Schedule for specific vehicles or special applications on page 33.

These exceptions are:

- Natural Gas Vehicles replace the gas tank(s)
- Class A Motorhome change the brake fluid
- Normal vehicle axle maintenance and lubrication
- Police and Taxi vehicle axles maintenance and lubrication

If you have any questions about your driving conditions, or for further clarification, please see your dealer.

6

Owner Checks and Services

Refer to Mileage Intervals for Additional Checks and Services

Certain basic maintenance checks and inspections should be performed by the owner or a service technician at the intervals indicated. Service information and supporting specifications are provided in the Owner's Guide.

Any adverse condition should be brought to the attention of your dealer or qualified service technician as soon as possible for the proper service advice. The owner maintenance service checks are generally not covered by warranties so you may be charged for labor, parts or lubricants used.

1

Check Every Month for All Vehicles:

- Check function of all interior and exterior lights
- Check tires for wear and proper air pressure
- Check engine oil fluid level
- Check windshield washer solvent fluid level
- Check and drain fuel/water separator (diesel vehicles)

Owner Checks and Services

~ /	

Check Every Six Months for All Vehicles:

- Check lap/shoulder belts and seat latches for wear and function
 Check air pressure in spare tire
 Check power steering fluid level
 Check washer spray, wiper operation, and clean all wiper blades
 Check parking brake for proper operation
 Check and lubricate all hinges, latches and outside locks
 Check and lubricate door rubber weatherstrips
 Check and clean body and door drain holes
 Check safety warning lamps (brake, ABS, air bag, safety belt) for operation
 Check cooling system fluid level and coolant strength
 Check battery water level (non-maintenance free)
- Check battery connections and clean if necessary
 Check clutch fluid level, if equipped



Every 5,000 miles

Adjust clutch by lifting pedal (manual transmission Mustang only)

0

The following section contains the "Normal Schedule." This schedule is presented at specific mileage intervals with exceptions noted. In addition, those items listed in italic type are additional services that **only** the noted vehicles require.

Additional Information Available on the Web

To learn more about the importance of routine and dealer-performed maintenance on your vehicle, please visit the Ford Customer Service website. You'll also find important warranty information, customer assistance, technical expertise, frequently asked questions and much more. The website location is at: www.ford.com/customerservice/

5,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear and rotate



Additional services for: Diesel

Check air filter minder, replace filter as required

10,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel


Check air filter minder, replace filter as required

10

Normal Sched

Normal Schedule

15,000 miles



Additional services for: Light Trucks, Sport Utilities, and Vans

- Inspect and lubricate 4X2 ball joints (except F-450/F-550)
- Inspect and lubricate steering linkage (E and F Series, Expedition, Navigator, Excursion)

Diesel

Additional services for: Diesel

- Check air filter minder, replace filter as required
- Replace fuel filter
- Add 8 to 10 oz. of FW16 coolant conditioner to cooling system

11

20,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

25,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles


- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

30,000 miles





Additional services for: Light Trucks, Sport Utilities, and Vans

- Inspect and lubricate 4X2 ball joints (except F-450/F-550)
- Inspect and lubricate steering linkage (E and F Series, Expedition, Navigator, Excursion)

^{*}If vehicle is registered in California, the California Air Resources Board has determined that the failure to perform this maintenance item will not nullify the emission warranty or limit recall liability prior to the completion of the vehicle's useful life. We, however, urge that all recommended maintenance services be performed at the indicated intervals and the maintenance be recorded.

	Di	es	el
•			

Additional services for: Diesel

- Check air filter minder, replace filter as required
 - Replace fuel filter
- Add 8 to 10 oz. of FW16 coolant conditioner to cooling system



Additional services for: Natural Gas Vehicles

◯ Inspect NGV tanks

35,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

Normal Schedule

40,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

45,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect automatic transmission fluid level, if equipped with dipstick
- Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking brake system
- Inspect engine cooling system and hoses
- Inspect steering linkage, suspension, and if equipped driveshaft and ball joints
- Inspect tires for wear and rotate
- Replace cabin air filter, if equipped
- Change green engine coolant, if equipped



Additional services for: Light Trucks, Sport Utilities, and Vans

- Inspect and lubricate 4X2 ball joints (except F-450/F-550)
- Inspect and lubricate steering linkage (E and F Series, Expedition, Navigator, Excursion)

Diesel

Additional services for: Diesel

- Check air filter minder, replace filter as required
- Replace fuel filter
- Add 8 to 10 oz. of FW16 coolant conditioner to cooling system

50,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

55,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

60,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking brake system
- Inspect engine cooling system and hoses
- Inspect exhaust system and heat shields
- Inspect steering linkage, suspension, and if equipped driveshaft and ball joints
- Inspect tires for wear and rotate
- Replace engine air filter

00000	Replace fuel filter* Replace cabin air filter, if equipped Inspect drive belt (Villager) Replace PCV valve (All 4 cylinder Ranger light trucks. See page 5.) Change automatic transmission/transaxle fluid on all vehicles equipped with AX4S, AX4N, 4R70W, 4R100, 4F27E. Inspect automatic transmission fluid level on all other vehicles, if equipped with dipstick. Consult your dealer for your particular requirements. Replace climate-controlled seat filters (Navigator, if equipped)			
	a	Additional services for: Light Trucks, Sport Utilities, and Vans		
	Lubricate 4X2 wheel bearing Change manual transmission	ball joints (except F-450/F-550) ngs, replace grease seals, and adjust bearings on fluid ing linkage (E and F Series, Expedition, Navigator,		
D ia	esel	Additional services for: Diesel		
0 0 0	Check air filter minder, re Replace fuel filter Add 8 to 10 oz. of FW16	place filter as required coolant conditioner to cooling system		

*If vehicle is registered in California, the California Air Resources Board has determined that the failure to perform this maintenance item will not nullify the emission warranty or limit recall liability prior to the completion of the vehicle's useful life. We, however, urge that all recommended maintenance services be performed at the indicated intervals and the maintenance be recorded.



Additional services for: Natural Gas Vehicles

Inspect NGV tanks

65,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

70,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

75,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect automatic transmission fluid level, if equipped with dipstick
- Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking brake system
- Inspect engine cooling system and hoses
- Inspect steering linkage, suspension, and if equipped driveshaft and ball joints
- Inspect tires for wear and rotate
- Replace cabin air filter, if equipped
- Change green engine coolant, if equipped



Additional services for: Light Trucks, Sport Utilities, and Vans

- Inspect and lubricate 4X2 ball joints (except F-450/F-550)
- Inspect and lubricate steering linkage (E and F Series, Expedition, Navigator, Excursion)

Check air filter minder, replace filter as required Replace fuel filter Add 8 to 10 oz. of FW16 coolant conditioner to cooling system Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles Change engine oil and replace oil filter

Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

85,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

Change engine oil and replace oil filter

Inspect tires for wear. Rotation recommended for optimal tire life.

Normal Schedule



Additional services for: Diesel

Check air filter minder, replace filter as required

90,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

Change	engine	oil	and	replace	oil	filte

Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking brake system

Inspect engine cooling system and hoses

Inspect exhaust system and heat shields

Inspect steering linkage, suspension, and if equipped driveshaft and ball joints

Inspect tires for wear and rotate

Replace engine air filter

Replace fuel filter*

Replace cabin air filter, if equipped

Inspect drive belt (Villager)

Change automatic transmission/transaxle fluid on all vehicles equipped with AX4S, AX4N, 4R70W, 4R100, 4F27E. Inspect automatic transmission fluid level on all other vehicles, if equipped with dipstick. Consult your dealer for your particular requirements.

Replace climate-controlled seat filters (Navigator, if equipped)

^{*}If vehicle is registered in California, the California Air Resources Board has determined that the failure to perform this maintenance item will not nullify the emission warranty or limit recall liability prior to the completion of the vehicle's useful life. We, however, urge that all recommended maintenance services be performed at the indicated intervals and the maintenance be recorded.



Additional services for: Light Trucks, Sport Utilities, and Vans

- Inspect and lubricate 4X2 ball joints (except F-450/F-550)
 Inspect and lubricate steering linkage (E and F Series, Expedition, Navigator,
 - Excursion)

Diesel

Additional services for: Diesel

- Check air filter minder, replace filter as required
- Replace fuel filter
- Add 8 to 10 oz. of FW16 coolant conditioner to cooling system



Additional services for: Natural Gas Vehicles

Inspect NGV tanks

95,000 miles





Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Normal Schedule

▲ Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

100,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles


- Change engine oil and replace oil filter
- Inspect accessory drive belt(s)
- Inspect tires for wear. Rotation recommended for optimal tire life.
- Replace spark plugs
- Replace the PCV on all passenger cars and light trucks under 6,000 Gross Vehicle Weight. (See page 5.)



Additional services for: Diesel

Check air filter minder, replace filter as required

105,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel **Vehicles**

- Change engine oil and replace oil filter
- Inspect automatic transmission fluid level, if equipped with dipstick
- Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking brake
- Inspect engine cooling system and hoses
- Inspect steering linkage, suspension, and if equipped driveshaft and ball joints
- Inspect tires for wear and rotate
- Replace cabin air filter, if equipped
- Change green engine coolant, if equipped
- Replace camshaft belt (Villager)



Additional services for: Light Trucks, Sport Utilities, and Vans

- Inspect and lubricate 4X2 ball joints (except F-450/F-550)
- Inspect and lubricate steering linkage (E and F Series, Expedition, Navigator, **Excursion**)

Diesel

Additional services for: Diesel

- Check air filter minder, replace filter as required
- Replace fuel filter
- Add 8 to 10 oz. of FW16 coolant conditioner to cooling system

Normal Schedule

110,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

115,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

26

Normal Schedule

120,000 miles

-	-	A	Diesel

Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

\bigcirc	Change engine oil and replace oil filter
\bigcirc	Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking brake
	system
\bigcirc	Inspect engine cooling system and hoses
\bigcirc	Inspect exhaust system and heat shields
\bigcirc	Inspect steering linkage, suspension, and if equipped driveshaft and ball joints
\bigcirc	Inspect tires for wear and rotate
\bigcirc	Replace engine air filter
\bigcirc	Replace fuel filter*
\bigcirc	Replace cabin air filter, if equipped
\bigcirc	Inspect drive belt (Villager)
\bigcirc	Replace PCV valve on all light trucks over 6,000 Gross Vehicle Weight and
	Rangers with 4 cylinder engines. (See page 5.)
\bigcirc	Change automatic transmission/transaxle fluid on all vehicles equipped with AX4S,
	AX4N, 4R70W, 4R100, 4F27E. Inspect automatic transmission fluid level on all other
	vehicles, if equipped with dipstick. Consult your dealer for your particular
	requirements.
\bigcirc	Inspect camshaft belt on all 2.0L, 4 cylinder engines (Escort, Tracer, Contour,
	Mystique, Cougar, and ZX2)
\bigcirc	Replace climate-controlled seat filters (Navigator, if equipped)

^{*}If vehicle is registered in California, the California Air Resources Board has determined that the failure to perform this maintenance item will not nullify the emission warranty or limit recall liability prior to the completion of the vehicle's useful life. We, however, urge that all recommended maintenance services be performed at the indicated intervals and the maintenance be recorded.



Additional services for: Light Trucks, Sport Utilities, and Vans

\bigcirc	Change manual transmission fluid
\bigcirc	Lubricate 4X2 wheel bearings (except F-450/F-550)
\bigcirc	Inspect and lubricate 4X2 ball joints (except F-450/F-550)
\bigcirc	Inspect camshaft belt on 4 cylinder engine (2.5L Ranger)

Inspect and lubricate steering linkage (E and F Series, Expedition, Navigator, Excursion)

▲ Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

Replace fuel filter

Add 8 to 10 oz. of FW16 coolant conditioner to cooling system



Additional services for: Natural Gas Vehicles

Drain coalescent fuel filter bowl and replace filter

Inspect NGV tanks

125,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

Change engine oil and replace oil filter

Inspect tires for wear. Rotation recommended for optimal tire life.

20



Additional services for: Diesel

Check air filter minder, replace filter as required

130,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

135,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect automatic transmission fluid level, if equipped with dipstick
- Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking brake system

29

	Inspect engine cooling system and hoses Inspect steering linkage, suspension, and if equipped driveshaft and ball joints Inspect tires for wear and rotate Replace cabin air filter, if equipped Replace green engine coolant, if equipped				
T	4	Additional services for: Light Trucks, Sport Utilities, and Vans			
	•	ball joints (except F-450/F-550) ing linkage (E and F Series, Expedition, Navigator,			
Die	esel	Additional services for: Diesel			
140,	Check air filter minder, rep Replace fuel filter Add 8 to 10 oz. of FW16	place filter as required coolant conditioner to cooling system			
	Change engine oil and rep	Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles			
$\overline{}$	change engine on and rep	iuce on iniei			

Inspect tires for wear. Rotation recommended for optimal tire life.

▲ Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

145,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect tires for wear. Rotation recommended for optimal tire life.

▲ Diesel

Additional services for: Diesel

Check air filter minder, replace filter as required

150,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4, Natural Gas, Propane, and Diesel Vehicles

- Change engine oil and replace oil filter
- Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking brake system
- Inspect engine cooling system and hoses

	Inspect exhaust system and heat shields					
	Inspect steering linkage, suspension, and if equipped driveshaft and ball joints					
	Inspect tires for wear and	rotate				
	Replace engine air filter					
	Replace fuel filter*					
	Replace cabin air filter, if	equipped				
	Replace orange engine coo	lant, if equipped				
\bigcirc	Change automatic transmis	sion/transaxle fluid and filter				
	Replace rear axle lubrican	t on all rear wheel drive (RWD) vehicles.				
	Inspect drive belt (Villager)				
	Replace climate-controlled	seat filters (Navigator, if equipped)				
AT .	a	Additional services for: Light Trucks, Sport Utilities, and Vans				
	Inspect and Juhricate 4X2	hall joints (except F-450/F-550)				
	Inspect and lubricate 4X2 ball joints (except F-450/F-550) Replace 4x2 wheel bearings, grease seals, lubricate and adjust bearings					
	'	ing linkage (E and F Series, Expedition, Navigator,				
	Excursion)	, , , , , , , , , , , , , , , , , , , ,				
TI						
-	₩	Additional services for: 4x4 Vehicles				
	Change front axle lubrican	†				
	Change transfer case fluid	•				
	go					
D ie	and .					
- Die	ser	Additional services for: Diesel				
	Check air filter minder, rej	place filter as required				
	Replace fuel filter					
🔘	Add 8 to 10 oz. of FW16	coolant conditioner to cooling system ir Resources board has determined that the tailure to perform this				
intenance item	ı will not nullify the emission warra	or resources Board has determined martine tailure to perform this nity or limit recall liability prior to the completion of the vehicle's useful enance services be performed at the indicated intervals and the				
ntenance be r		enance services be performed at the indicated intervals and the				



Additional services for: Natural Gas Vehicles

Inspect NGV tanks

Exceptions

In addition, there are several exceptions to the Normal Schedule. They are listed below:

Natural Gas and Propane Vehicles

Every 15 years - Replace NGV or propane fuel tank(s)

Class A Motorhome

- Every two years Change brake fluid
- Every 30,000 miles Change automatic transmission fluid

Normal Vehicle Axle Maintenance

Rear axles containing synthetic lubricant and light duty trucks equipped with Ford-design axles are lubricated for life. These lubricants are not to be checked or changed unless a leak is suspected, service is required or the axle assembly has been submerged in water. The axle lubricant should be changed anytime the axle has been submerged in water.

Non-synthetic rear axle lubricants should be replaced every 3,000 miles or 3 months, whichever occurs first, during extended trailer tow operation above 21 Celsius (70 degrees Fahrenheit) ambient and wide open throttle for extended periods above 45 mph. The 3,000 mile lube change interval may be waived

if the axle was filled with 75W140 synthetic gear lubricant meeting Ford specification WSL-M2C192-A, part number F1TZ-19580-B or equivalent. Add four ounces of additive friction modifier C8AZ-19B546-A (EST-M2C118-A) or equivalent for complete refill of Traction-Lok rear axles. The rear axle lubricant should be changed anytime the axle has been submerged in water.

Police and Taxi Vehicle Axle Maintenance

Replace rear axle lubricant every 160,000 km (100,000 miles). Rear axle lubricant change may be waived if the axle was filled with 75W140 synthetic gear lubricant meeting Ford specification WSL-M2C192-A, part number FITZ-19580-B or equivalent. Add four ounces of additive friction modifier C8AZ-19B546-A (EST-M2C118-A) or equivalent for complete refill of Traction-Lok rear axles. The rear axle lubricant should be changed anytime the axle has been submerged in water.

F-450 and F-550 Axle Maintenance

Replace rear axle lubricant every 100,000 miles under normal driving conditions on all F-450 and F-550 commercial applictions. For F-450 and F-550 trucks operated at or near maximum Gross Vehicle Weight Ratings, the rear axle lubricant should be replaced every 50,000 miles. In addition, this 50,000 mile schedule should be observed when the vehicles are operated under the Special Operating Conditions, where noted, beginning on page 36.

Special Operating Conditions

Items Needing Special Attention

If you operate your Ford/Lincoln/Mercury **primarily** in one of the more demanding "Special Operating Conditions" listed below, you will need to have some items maintained more frequently. If you only occasionally operate your vehicle under these conditions, it is not necessary to perform the additional maintenance. For specific recommendations, see your dealership service advisor or qualified service professional.



Towing a trailer or using a camper or car-top carrier

Every 3,000 miles or 3 months Change engine oil and replace oil filter

Every 30,000 miles Change automatic transmission fluid

Every 60,000 miles Change transfer case fluid

As required Change manual transmission fluid
As required Inspect and lubricate U-joints



Extensive idling and/or low-speed driving for long distances as in heavy commercial use such as delivery, taxi, patrol car or livery

Every 3,000 miles or 3 months Change engine oil and replace oil filter

Lube front lower control arm ball joints with zerk

fittings, if equipped

Every 5,000 miles Inspect brake system **Every 15,000 miles** Replace fuel filter

Every 30,000 miles Change automatic transmission fluid

Lubricate 4x2 wheel bearings, replace grease seals, and

adjust bearings

Every 60,000 miles Replace spark plugs

Change transfer case fluid

As required Replace cabin air filter

Special Operating Conditions



Operating in dusty conditions such as unpaved or dusty roads

Every 3,000 miles or 3 months Change engine oil and replace oil filter

Every 15,000 miles Replace fuel filter

Every 30,000 miles Change automatic transmission fluid

Every 50,000 miles Change rear axle lubricant (F-450 and F-550 only)

Every 60,000 miles Change transfer case fluid

As required Replace engine air filter

As required Replace cabin air filter



Off-road operation

Every 30,000 miles Change automatic transmission fluid

Every 50,000 miles Change rear axle lubricant (F-450 and F-550 only)

Every 60,000 miles Change transfer case fluid
As required Replace cabin air-filter
As required Inspect and lubricate U-joints

Maintenance and Service Record

See An Authorized Dealer

This section of the guide is designed to allow your Ford or Lincoln Mercury dealer, or Ford or Lincoln Mercury Auto Care service center or other qualified service technician to record that the recommended service was completed at the appropriate mileage intervals. Be sure to ask your service provider to record the type of service rendered (Normal or Special Operating Conditions — SOC) each time service is performed.

Date: Mileage: Normal SOC	Dealer's Stamp:	
See corresponding	See corresponding mileage in maintenance schedule for services performed.	
Date: Mileage: Normal SOC	Dealer's Stamp:	
See corresponding mileage in maintenance schedule for services performed.		
Date: Mileage: Normal SOC	Dealer's Stamp:	

See corresponding mileage in maintenance schedule for services performed.

Date: Mileage: Normal SOC See correspondin	Dealer's Stamp: Ig mileage in maintenance schedule for services performed.
Date: Mileage: Normal SOC	Dealer's Stamp:
See correspondin	ng mileage in maintenance schedule for services performed.
Date: Mileage: Normal SOC	Dealer's Stamp:
See corresponding mileage in maintenance schedule for services performed.	
Date: Mileage: Normal SOC	Dealer's Stamp:

		1-
Date: Mileage: Normal SOC	Dealer's Stamp:	Maintenance and Service Record
See correspondin	g mileage in maintenance schedule for services performed.	d Serv
Date: Mileage: Normal SOC	Dealer's Stamp:	rice Record
See correspondin	g mileage in maintenance schedule for services performed.	
Date: Mileage: Normal SOC	Dealer's Stamp:	
See correspondin	g mileage in maintenance schedule for services performed.	
Date: Mileage: Normal SOC	Dealer's Stamp:	
See correspondin	a mileage in maintenance schedule for services performed	ı

Date: Mileage: Normal SOC See correspondin	Dealer's Stamp: ng mileage in maintenance schedule for services performed.
Date: Mileage: Normal SOC	Dealer's Stamp:
See correspondir	ng mileage in maintenance schedule for services performed.
Date: Mileage: Normal SOC	Dealer's Stamp:
See corresponding mileage in maintenance schedule for services performed.	
Date: Mileage: Normal SOC	Dealer's Stamp:

Date: Mileage:	Dealer's Stamp:
Normal SOC	
See correspondin	ng mileage in maintenance schedule for services performed.
Date: Mileage: Normal SOC	Dealer's Stamp:
See corresponding mileage in maintenance schedule for services performed.	
Date: Mileage: Normal SOC	Dealer's Stamp:
See correspondin	ng mileage in maintenance schedule for services performed.
Date: Mileage: Normal SOC	Dealer's Stamp:
See correspondir	ng milegge in maintenance schedule for services performed

e corresponding mileage in maintenance schedule for services performed.

Date: Mileage: Normal SOC	Dealer's Stamp: Ig mileage in maintenance schedule for services performed.
et	3 Political and the second second political and the second polit
Date: Mileage: Normal SOC	Dealer's Stamp:
See correspondii	ng mileage in maintenance schedule for services performed.
Date: Mileage: Normal SOC	Dealer's Stamp:
See corresponding mileage in maintenance schedule for services performed.	
Date: Mileage: Normal SOC	Dealer's Stamp:
£	

		1-
Date: Mileage: Normal SOC	Dealer's Stamp:	Maintenance and Service Record
See correspondin	g mileage in maintenance schedule for services performed.	d Serv
Date: Mileage: Normal SOC	Dealer's Stamp:	rice Record
See correspondin	g mileage in maintenance schedule for services performed.	
Date: Mileage: Normal SOC	Dealer's Stamp:	
See correspondin	g mileage in maintenance schedule for services performed.	
Date: Mileage: Normal SOC	Dealer's Stamp:	
See correspondin	a mileage in maintenance schedule for services performed	ı

corresponding mileage in maintenance schedule for services performed.

Date: Mileage: Normal	Dealer's Stamp:
soc 🗍	
See correspondi	ng mileage in maintenance schedule for services performed.
Date: Mileage: Normal	Dealer's Stamp:
soc	
See correspondi	ng mileage in maintenance schedule for services performed.
Date: Mileage:	Dealer's Stamp:
Normal SOC	
See correspondi	ng mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage: Normal SOC	
See correspondi	ng mileage in maintenance schedule for services performed.

Date: Mileage: Normal SOC	Dealer's Stamp:
See correspondin	ng mileage in maintenance schedule for services performed.
Date: Mileage: Normal SOC	Dealer's Stamp:
See correspondin	ng mileage in maintenance schedule for services performed.
Date: Mileage: Normal SOC	Dealer's Stamp:
See correspondin	ng mileage in maintenance schedule for services performed.
Date: Mileage: Normal SOC	Dealer's Stamp:

See corresponding mileage in maintenance schedule for services performed

Dealer's Stamp: ng mileage in maintenance schedule for services performed.
Dealer's Stamp:
ng mileage in maintenance schedule for services performed.
Dealer's Stamp:
ng mileage in maintenance schedule for services performed.
Dealer's Stamp:

See corresponding mileage in maintenance schedule for services performed.

		l >
Date:	Dealer's Stamp:	≧
Mileage:		뭁
Normal		ğ
SOC		۱Ž
	e	ı
See correspondin	g mileage in maintenance schedule for services performed.	Maintenance and Service Record
Date:	Dealer's Stamp:	<u>₹</u> .
Mileage:		°
_		
Normal SOC		ᇍ
300		
See correspondir	g mileage in maintenance schedule for services performed.	
300 torrosponan	g militage in manifestance schedule for soffices performed.	
Date:	Dealer's Stamp:	
Mileage:	5 3 mm, 5 3 mm, 6	
_		
Normal SOC		
300		
Soo correspondi	g mileage in maintenance schedule for services performed.	
See Correspondin	y illieuge ill illullitelulite schedole for services performed.	
Date:	Dealer's Stamp:	
Mileage:	·	
_		
Normal SOC		
300		
Soo correspondi	na milanna in maintannna achadula far carriera narfarmad	

corresponding mileage in maintenance schedule for services performed.

Dealer's Stamp: ng mileage in maintenance schedule for services performed.
Dealer's Stamp:
ng mileage in maintenance schedule for services performed.
Dealer's Stamp:
ng mileage in maintenance schedule for services performed.
Dealer's Stamp:

See corresponding mileage in maintenance schedule for services performed.